

WOTCHi

THE SMARTWATCH

D32

1.Preparation Before Using

1. Check whether the products and accessories are complete.
2. Prepare a Nano SIM card, please refer to the dealer's opinion for details. (Please turn off the phone before installing the card)
3. The watch SIM card needs to activate the mobile data function and caller ID function. The telecommunications card needs to activate the volte function.
4. Install the APP client on the mobile phone, and ask your dealer for details of the client.

2.Insert SIM Card

Take out the card tray, put the SIM card chip facing up, and put it on the card tray, insert the device with the notch facing inward.

3.On/Off


Power on: Long press power button for 3 seconds, there will be vibration when the watch is turning on. Power off: Turn it off through Shutdown option in "Setting" menu. Please note that do not remove the sim card directly when it is on, in order to prevent the card from broken.

7.APP Installation And Use


1. Android system user: download 'SeTracker 2' from Google Play, IOS system user: download 'Se Tracker 2' from APP store. Or scan below QR code to download 'SeTracker 2'.



2. Open the APP after installation, the APP supports 32 languages. Click to register, please use your email account to register and complete the registration according to the prompts. The account will be logged in automatically after registration. (Note: There are five areas: Asia and Oceania, Hong Kong, Europe and Africa, South America, North America. Please select the related server according to your region when registering, otherwise the watch will be unable to connect to the APP, which will affect normal use of the watch).




9. Positioning: You can check the real-time location of the watch. The position of both the watch and mobile phone will be showed on the map. Click "locating" to perform the real time location. Three location modes are distinguished by different color: GPS (Red icon), LBS (Blue icon), WIFI (Green icon).




10. Historical track: You can check the watch' history route by different time. The base location switch on this menu refers to the switch that shows the base station point when checking history route, it shows base location route when it turns on, but not when it is turned off.

15. Do not disturb: During no disturbing period, out coming calls will be banned, and the watch is not able to enter to other interface.




16. SMS Alerts: Low battery, SOS alert, Alert message will be sent to the guardian's number which can be set by APP.

21. Health: Steps function can be used when you switch on it on the APP manually.



22. Message: To check all the alert SMS for the watch.

27. Personal settings: Click "ME", it contains edit personal profile, add/delete device or change password, sign out.



Please read this manual carefully before using the product and keep it properly. The color is subject to the real product.

Package contents: watch (including strap) D32, charger D32, D32 product manual

Kids smartwatch 4G

D32

Product description



4.Power Button Operation Instructions

SOS calling: After installing sim card and connecting to APP, long press the SOS button, the watch will automatically call the preset three SOS numbers in APP. Three phone numbers will be called one after another twice (unless the call is answered).

5.Instructions




Picture Only For Reference

3. Log into the homepage after registration to bind the watch, "Me" → device list → "Add device", scan the QR code or manually input the 15-bit registration code.

8.Main Function Instruction:

1. Video calling: After the watch bound to the APP, the watch and the bound APP can make two-way video call. When the watch is bound to multiple APP accounts, group video calling can be made.
2. Talk: Two-way voice messages (up to 15 seconds) and one-way text messages (up to 15 characters).
3. Voice message: Long press "Voice" to record voice message and release to send to APP. The watch will receive the notification of voice message (The time of receipt depends on the network condition), click to play the voice message
4. Text message: Only supporting APP send text message to the watch. The watch can read the text message but cannot send text message to APP.
5. Take-off alert: When the children take off the watch, APP will receive take-off alert message.
6. Call record: It supports to check recent call records for replying in time



11. Setting: Set the parameters of the watch (Click the setting button and go to the following page).




12. Language: Switch different language manually (now it supports 15 languages).

17. SOS number: After installing sim card and connecting to APP, long press the SOS button, the watch will automatically call the preset three SOS numbers in APP. Three phone numbers will be called one after another twice (unless the call is answered). (The default is off, which you can activate it in message alert).



18. Phone book: You can set 15 different numbers by APP, watch can make two-way phone call with these numbers once you set successfully. The watch will block the numbers out of phone book.

23. Alarm clock: 3 alarms can be set as required.




24. Rewards: Set love number and click ok to send it to the watch, watch will show the love it received, up to 99 hearts can be set.

Reminds :

- A: Maximum 50 devices can be bound by one account. Check watch IMEI on the device information menu, if it's different from IMEI sticker on the back case of the watch, the watch is not able to connect with APP.
- B: Switch online device: If multi devices are controlled by one account, click device icon to switch one device to another.
- C: Alarm indicator for the watch: Click the information menu of APP on the mobile phone to enter information center to see the specific alert content.

6.Introduction Of APP Main Interface



7. Remote photography: You can send commands to take a picture of the surroundings of the watch, and the photos will be uploaded to the APP, you can check the photos from below interface (Sometimes the uploading of the pictures will be delayed due to the network, please wait patiently or send more commands)



8. GEOFENCE: The minimum radius is 200 meters. When the watch goes out of the fence, there is an alarm message to APP. You only can set three GEOFENCE.

13. Sound Guardian: Input guardian's number, then click 'ok' to send the demand of remote monitoring. Watch will call that number automatically when it receive the demands. When the phone receives a call from the watch, guardian can hear the watch surrounding sound, but the watch user cannot hear the sound from the phone.



14. Watch working mode: There are 2 different kinds of time interval operation mode: normal mode, power save mode, different mode, different data update interval will has different consumption to the watch, we recommend users to set for normal mode or power save mode.

19. Remote shutdown: When the watch is switched on and connect to APP, it can be remote shutdown from the APP.



20. Remote restart: When the watch is switched on and connect to APP, it can be remote restarted from the APP.

25. Remote photography: Click remote camera on the APP to control the watch to take remote photos.



26. Watch finder: When the watch is out of your eyes, you can click "watch finder" demand on the app, the watch will ring, click the button on the watch to stop ring.

WOTCHi

THE SMARTWATCH

